



# TP70/P5 Protocol for ICT002 / Pulse

GTQ6 Support bill 1、5、10、20、50、100 (Guatemala)

## DIP SW SETTING : 1

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
Normal Pulse	Special Pulse										
★ 1 Pulse / GTQ 1	1 Pulse / GTQ 5	OFF	OFF	OFF							
2 Pulse / GTQ 1	1 Pulse / GTQ 10	OFF	OFF	ON							
3 Pulse / GTQ 1	1 Pulse / GTQ 20	OFF	ON	OFF							
4 Pulse / GTQ 1	1 Pulse / GTQ 50	OFF	ON	ON							
5 Pulse / GTQ 1	1 Pulse / GTQ 100	ON	OFF	OFF							
10 Pulse / GTQ 1	1 Pulse / GTQ 500	ON	OFF	ON							
20 Pulse / GTQ 1	1 Pulse / GTQ 1000	ON	ON	OFF							
100 Pulse / GTQ 1	1 Pulse / GTQ 10000	ON	ON	ON							
Fast Output Pulse	Lo=50ms Hi=100ms				ON						
★ Slow Output Pulse	Lo=50ms Hi=300ms				OFF						
Inhibit level Active Low						ON					
★ Inhibit level Active High						OFF					
★ Accept GTQ 1 & 5							ON				
Reject GTQ 1 & 5							OFF				
★ Accept GTQ 10								ON			
Reject GTQ 10								OFF			
★ Accept GTQ 20									ON		
Reject GTQ 20									OFF		
★ Accept GTQ 50										ON	
Reject GTQ 50										OFF	
★ Accept GTQ 100											ON
Reject GTQ 100											OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip Switch 1 to 5 are only for Pulse mode.

## DIP SW SETTING : 2

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High (NO)	ON			
Pulse Normal Low (NC)	OFF			
★ Pulse Protocol		ON		
ICT Protocol		OFF		
Straight			ON	
★ Turn Over			OFF	
Special Pulse(note3)				ON
★ Normal Pulse				OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after any changes on Dip switch

(2) Dip Switches 1 & 3 are only used for pulse protocol.

(3) Accumulated to the set value, then send a Pulse.